


Exhibit A

Part 3


Reading Data on the Hard Disk

The Read Head senses the transitions, converts them to a voltage signal and sends that signal to the Read Channel Detector



Reading Data on the Hard Disk

The strongest electromagnetic field is found at the ends (north pole/south pole) of the bar magnet's




Reading Data on the Hard Disk



Read Channel Detector
Detects the data written to the disk


Reading Data on the Hard Disk

The Read Channel Detector samples the signal at regular time intervals and uses those values to attempt to determine the sequence of data symbols written on the disk



Reading Data on the Hard Disk


The Read Channel Detector samples the signal at regular time intervals and uses those values to attempt to determine the sequence of data symbols written on the disk



exaggerated in FIG. 3. FIG. 3 also shows the written symbols a_1, \dots, a_{18} , as well as the samples r_1, \dots, r_{18} of the read-back waveform, sampled at the rate of one sample per symbol interval.


Reading Data on the Hard Disk

In the past, when data density was much lower, it was easier to detect the data from the readback signal




Reading Data on the Hard Disk

As data density increased, the noise became more of a problem and accurate reading became more difficult




Reading Data on the Hard Disk

As data density increased, the noise became more of a problem and accurate reading became more difficult




Reading Data on the Hard Disk

The Kavcic-Moura Invention is a detector with the ability to accurately detect digital data from today's high-density hard drives




Noise on a Magnetic Hard Disk

A “Noise-Free” Signal, the Actual Readback Signal, and the Noise




-  Hypothetical “Noise-Free” Signal for this bit pattern
-  Actual Readback Signal generated by the Read Head
-  Noise

Correlated Noise



-  Hypothetical "Noise-Free" Signal for this bit pattern
-  Actual Readback Signal generated by the Read Head
-  Noise

Correlated Noise




In high density magnetic recording, noise samples corresponding to adjacent signal samples are heavily correlated as a result of front-end equalizers, media noise, and signal nonlinearities combined with nonlinear filters to cancel them. This correlation deteriorates significantly the performance of detectors at high densities.



Source: '839 Patent
(2:2-7)

Signal Dependent Noise



- Hypothetical “Noise-Free” Signal for this bit pattern
- Actual Readback Signal generated by the Read Head
- Noise


Signal Dependent Noise

The trellis/tree branch metric computation of the present invention is correlation-sensitive, being both signal-dependent and sensitive to correlations between noise samples. This method is termed the correlation-sensitive

data. These covariance matrices are different for each branch of the tree/trellis due to the signal dependent structure of the media noise. Because the channel characteristics in mag-


M_i represents the branch metric of the trellis/tree in the Viterbi-like algorithm. The metric is a function of the observed samples $r_i, r_{i+1}, \dots, r_{i+L}$. It is also dependent on the postulated sequence of written symbols $a_i - K_1, \dots, a_i + L + K_p$, which ensures the signal-dependence of the detector. As a consequence, the branch metrics for every branch in the tree/trellis is based on its corresponding signal/noise statistics.

Signal Dependent Noise



-  Hypothetical "Noise-Free" Signal for this bit pattern
-  Actual Readback Signal generated by the Read Head


Signal Dependent Noise



data. These covariance matrices are different for each branch of the tree/trellis due to the **signal dependent structure of the media noise**. Because the channel characteristics in mag-

-  Hypothetical "Noise-Free" Signal for this bit pattern
-  Actual Readback Signal generated by the Read Head


The Impact of the Noise Increases in High-Density Environments



Increasing the data density increases the impact of the correlated and signal-dependent noise so nearby transitions affect each other more

-  Hypothetical “Noise-Free” Signal for this bit pattern
-  Actual Readback Signal generated by the Read Head

The Impact of the Noise Increases in High-Density Environments



Increasing the data density increases the impact of the signal-dependent and correlated noise so nearby transitions affect each other more

-  Hypothetical “Noise-Free” Signal for this bit pattern
-  Actual Readback Signal generated by the Read Head